

Drain Tee Cap & Hose Connection

Z-VENT® Drain Tee Caps are equipped with a ½inch diameter drain fitting to allow the evacuation of condensate from the vent system.

NOTE: This fitting protrudes ½inch and has an internal thread that serves NO purpose to the installer.

NOTHING IS TO THREAD INTO THIS DRAIN FITTING.

Z-Flex® recommends the installation of the tube kit 2SVEDTK__ to facilitate the evacuation of the condensate to a suitable drain or neutralizing system.

The Tube Kit Contains:

- 1 ½ inch wire (hose) clamp
- 2 Cable ties
- 1 ¾ inch ID / ⅝ inch OD Silicone Tube (various lengths)

1. Open wire clamp with pliers and slide over the tubing.
2. Form a 3 inch loop in the tubing and affix the cable tie to complete the p-trap.
3. Fill the p-trap with water.
4. Affix the tubing onto the drain fitting.
5. Open the wire clamp and slide the clamp back to the end of the tube over the drain fitting and release.
6. This tube can be extended by adding suitable size hose and nipple connection.

Detailed installation instructions can be viewed in the **Z-VENT® Information Center** at www.z-flex.com

